

DSA-1 Manager
Operation Manual



DSA-1 Manager

Operation Manual

by Ian Dennis

This manual is also available as 'on-line help' from the dScope software. You can access the on-line help from the 'Help' menu.

Table of Contents

Part 1	General information	1
Part 2	Introduction	2
1	PC requirements	2
2	About this manual	2
Part 3	Getting started	3
1	Software installation	3
2	Connecting the DSA-1	3
	USB-COM adapter	3
Part 4	Using the DSA-1 Manager	4
1	User interface	4
2	Uploading a Results Log	4
3	Remote Control	4
4	Test Sequences	5
5	Updating the DSA-1 firmware	7
Part 5	Menu reference	9
1	File menu	9
2	Edit menu	9
3	Search menu	10
4	Format menu	10
5	DSA-1 menu	10
6	Help menu	11
Part 6	Test Sequence authoring guide	12
1	Elements of a Test Sequence	12
2	Language reference	13
Part 7	Icons and Hotkeys reference	18
1	Toolbar icons	18
2	Hotkeys (short-cut keys)	19
	Index	20

1 General information

Manual revision history

Rev	Date	Author	Notes
1.00	8th October 2005	I.G.Dennis	To accompany software 1.0.0

Support contacts

Prism Media Products Limited
William James House
Cowley Road
Cambridge CB4 0WX
UK

Prism Media Products Inc
21 Pine Street
Rockaway
NJ 07866
USA

Telephone: +44 1223 424988

Telephone: +1 973 983 9577

Fax: +44 1223 425023

Fax: +1 973 983 9588

Email: tech.support@prismsound.com

Web: <http://www.prismsound.com>

Or contact your local Prism Sound distributor as detailed on the website.

Trademark acknowledgements

Microsoft, MS-DOS, Visual Basic, VB, VBA, VBScript, Visual C++ and Windows are trademarks of Microsoft Corporation.

All trademarks acknowledged

© 2005 Prism Media Products Limited. All rights reserved.

This manual may not be reproduced in whole or part, in any medium, without the written permission of Prism Media Products Limited.

In accordance with our policy of continual development, features and specifications are subject to change without notice.

2 Introduction

The DSA-1 Manager is a Windows program which allows the DSA-1 hand-held analyzer to be used with a PC.

The DSA-1 Manager provides four functions:

Results Log uploader	Uploads the contents of the DSA-1's non-volatile Results Log to the PC for printing, inclusion in reports etc.
Remote Control window	Allows the DSA-1 to be remote controlled using screen and mouse.
Test Sequence compiler/downloader	Allows user-defined Test Sequences to be edited, compiled and downloaded to the DSA-1.
Firmware downloader	Updates the DSA-1's firmware.

2.1 PC requirements

The DSA-1 Manager runs on almost any PC running Windows 95, 98, 2000 or XP.

The PC must have a serial (COM) port available for connection to the DSA-1. Alternatively, a USB port (1.0 or higher) can be used with the USB-COM adapter supplied.

2.2 About this manual

This manual is provided in two different formats: as a conventional manual in 'pdf' format, and also as 'online help' which can be viewed whilst operating the DSA-1 Manager. The pdf version is best viewed with Adobe Acrobat Reader, which can be downloaded free at www.adobe.com. The latest versions of both software and manual are available from the Prism Sound website at www.prismsound.com.

3 Getting started

The following sections contain details of how to [install the DSA-1 Manager software](#), and how to [connect the DSA-1 to the PC](#).

3.1 Software installation

To install the DSA-1 Manager software, run the installation executable 'setup.exe' in the 'DSA-1 Manager' folder and follow the instructions which appear on the screen during installation. The installation executable is supplied with new DSA-1s on a USB flash disk. For existing DSA-1 owners, or those who cannot read the USB flash disk (e.g. Windows 95 or 98 users), the latest installation executable can be downloaded free of charge from www.prismsound.com.

3.2 Connecting the DSA-1

If the DSA-1 is to be connected to a COM port on the PC, simply connect the 9-way COM port connector on the PC to the similar 'RS232C' connector on the DSA-1 using a null-modem ('cross-over') cable, as supplied with the DSA-1.

If a USB port on the PC is to be used, it is first necessary to install the USB-COM adapter (supplied) as described in the [USB-COM adapter](#) section.

Having connected the DSA-1, and installed the USB-COM adapter if required, the appropriate COM port can be selected from within the DSA-1 Manager software using the 'Select COM port' option in the DSA-1 menu.

3.2.1 USB-COM adapter

To install the USB-COM adapter, run the installation executable 'setup.exe' in the 'USB-COM' folder and follow the on-screen instructions. The end result is that a 'virtual COM port' is established for the USB-COM adapter which can be nominated as the DSA-1 connection port within DSA-1 Manager.

4 Using the DSA-1 Manager

This section contains basic details of how to use the DSA-1 Manager. For more details, see the [Menu reference](#) and [Icons and Hotkeys reference](#) sections.

4.1 User interface

The DSA-1 Manager's user interface looks rather like any Windows text editor, for example Windows Notepad. The text editor is used to edit DSA-1 Test Sequences prior to compilation and downloading to the DSA-1. It is also used as a repository for uploaded Results Logs from the DSA-1.

The menus, icons and hotkeys which relate to the text editor will hopefully be familiar to Windows users; they are not discussed here but are covered in the [Menu reference](#) and [Icons and Hotkeys reference](#) sections.

The following sections summarise operation of the DSA-1 Manager's four functions:

Results Log uploader	Uploads the contents of the DSA-1's non-volatile Results Log to the PC for printing, inclusion in reports etc.
Remote Control window	Allows the DSA-1 to be remote controlled using screen and mouse.
Test Sequence compiler/downloader	Allows user-defined Test Sequences to be edited, compiled and downloaded to the DSA-1.
Firmware downloader	Updates the DSA-1's firmware.

4.2 Uploading a Results Log

The DSA-1 has a non-volatile Results Log into which the user can store test and measurement results. Operation of the Results Log is described in section 6.8 of the DSA-1 Operation Manual.

The DSA-1 Manager can upload the contents of the Results Log into its text window. To do this, select 'Upload Results Log' from the DSA-1 menu. Alternatively, you can use the  icon or [F10] hotkey. Note that the DSA-1 must be connected to the PC as described in the section [Connecting the DSA-1](#), and must be switched on.

Once the Results Log is uploaded, it can be edited, saved or transferred into other Windows applications via the clipboard.

4.3 Remote Control

The DSA-1 can be remotely controlled from the screen and mouse of the PC.

To open the Remote Control window, select 'Remote Control' from the DSA-1 menu. Alternatively, you can use the  icon or [F8] hotkey. Note that the DSA-1 must be connected to the PC as described in the section [Connecting the DSA-1](#), and must be switched on.



It is possible to use the Remote Control facility over a long distance by using a local area network or an internet connection between the PC running the DSA-1 Manager software and a remote PC connected to the DSA-1.

4.4 Test Sequences

The DSA-1 has the capability to run 'Test Sequences'. These are pre-programmed series of tests which are held in the DSA-1's non-volatile memory. Test Sequences allow an operator to run through many tests in sequence at the press of a button. The DSA-1 draws the operator's attention to any failures within the sequence of tests. Operation of the Test Sequence feature is described in section 4.5 of the DSA-1 Operation Manual.

The DSA-1 has four 'burned-in' Test Sequences which cannot be changed by the user, plus space for up to four 'user' Test Sequences. The 'user' Test Sequences are created, compiled and downloaded into the DSA-1 using the DSA-1 Manager.

[Creating a source file](#)

'User' Test Sequences are written in a special language, which is detailed in the [Test Sequence authoring guide](#) section. Test Sequences are initially written using the text window. It may be useful to start from the 'source file' of one of the 'burned in' Test Sequences rather than beginning your 'user' Test Sequence from scratch. These files are installed with the DSA-1 Manager, and are listed in Appendix C of the DSA-1 Operation Manual.

The 'burned-in' Test Sequences are:

Test Name	Source file
Global Test	DSATST1.TXT, DSATST1A.TXT
Consumer Test	DSATST2.TXT, DSATST2A.TXT
General Pro Test	DSATST3.TXT, DSATST3A.TXT
Strict Pro Test	DSATST4.TXT, DSATST4A.TXT


Note that the 'A' versions are functionally identical to their non-A counterparts, but incorporate 'programmer-friendly units'. The original files (with native units) are provided only for backward compatibility. It is recommended that the 'A' versions are used.

To begin work with one of these files, simply load it into the text window and you can begin to modify it, for example changing limit values. You will notice that the source code is helpfully coloured by the editor, which understands the syntax of the language. If the colouring needs to be manually refreshed, use the 'Refresh Syntax Colour' option within the Test Sequence submenu of the DSA-1 menu, or use the 'F5' hotkey.

When the source code is complete, save it to disk before proceeding in order that your code is not accidentally lost. If you began from one of the 'burned-in' Test Sequence source files, make sure that you save your modified version to a different file name so that the original is not over-written.

Compiling a Test Sequence

Once the source code is complete (and saved to disk), compile the Test Sequence by selecting the 'Compile...' option from the Test Sequence submenu in the DSA-1 menu. Alternatively, you can use the  icon or [F6] hotkey. The following dialogue box is displayed:




It is possible (though usually unnecessary) to modify the file names and paths for the source file to be compiled, as the destinations for the compilation listing (.LST) and executable (.BIN) files.

On clicking the [Compile] button, the Test Sequence is compiled. If success or failure of the compilation is displayed in a message box. If the compilation failed (i.e. if there was an error in the .TXT source file) then the .LST file is automatically loaded into the text window. The .LST contains a line-by-line summary of the compilation, with error messages displayed where they were encountered. Once the source of the error has been identified, the .TXT file must be reloaded, repaired, and resaved before recompiling.

Downloading a Test Sequence

Once the Test Sequence has been compiled successfully, it is downloaded into the DSA-1 by selecting the 'Download...' option from the Test Sequence submenu in the DSA-1 menu.

Alternatively, you can use the  icon or [F7] hotkey. The following dialogue box is displayed:



A 'User' Test Sequence executable (.BIN) can be nominated for any of the four 'user' slots. Alternatively, a slot can be left as it is by selecting 'skip', or cleared by selecting the 'BLANK.BIN' executable.

On clicking the [Download] button, the selected Test Sequence executables are downloaded into the DSA-1. Note that the DSA-1 must be connected to the PC as described in the section [Connecting the DSA-1](#), and must be switched on.

4.5 Updating the DSA-1 firmware

⚠ WARNING! Care must be taken when updating the DSA-1 firmware. Interruption of the process (for example if the null-modem cable or power supply is removed, or if the PC is crashed) can leave the DSA-1 in an inoperable state. For this reason, it is recommended that the firmware is only updated at such times as new versions of the firmware are released.

To update the DSA-1 firmware, connect the DSA-1 to the PC as described in the section [Connecting the DSA-1](#). Ensure that the DSA-1 is connected to its external DC supply, and that the supply is switched on. Turn the DSA-1 on by pressing the [ON] button WHILST THE [DI] AND [EDIT/CLEAR] BUTTONS ARE PRESSED. The DSA-1 will display the message 'DSA-1 Download... Waiting...' if the firmware download mode has been successfully entered.

In the DSA-1 Manager, select 'Download Firmware upgrade...' from the DSA-1 menu. Select the desired firmware download (.DLD) file. The latest file is available at www.prismsound.com.



Click the [Download] button to start the update, which takes approximately two minutes. The progress of the update is shown in the dialogue box; the DSA-1's display also shows a diagnostic list of the flash blocks being updated.

When the update is complete, the DSA-1 restarts automatically. Note that a firmware update causes the DSA-1 settings to revert to the factory defaults, and clears both the Results Log and the user Test Sequence slots.

5 Menu reference

The menu reference section provides detailed descriptions of all the available menus options.

The available menus are as follows:

File menu	Loading and saving files, printing etc.
Edit menu	Editing operations; cut, paste etc.
Search menu	Search and replace functions
Format menu	Text formatting functions
DSA-1 menu	Accesses all DSA-1 specific functions: uploading the Results Log, compiling and downloading Test Sequences, Remote Control and firmware updates
Help menu	Access to on-line help and version information

5.1 File menu

The File menu accesses typical file-related functions, similar to those of any text editor.

File menu options are:

New	Opens a new document
Open...	Opens an existing document
Save	Saves the current document to same location
Save as...	Saves the current document to a new location
Print...	Prints the current document
Page setup...	Allows basic page formatting for print
Exit	Exits the DSA-1 Manager

5.2 Edit menu

The Edit menu accesses typical edit-related functions, similar to those of any text editor.

Edit menu options are:

Undo	Reverses the last edit action
Cut	Cuts selected text to the clipboard
Copy	Copies selected text to the clipboard
Paste	Inserts clipboard contents at cursor
Select All	Selects all text in the current document

5.3 Search menu

The Search menu accesses typical search-related functions, similar to those of any text editor.

Search menu options are:

Find...	Initiates finding of text in current document
Find Next	Finds the next instance of existing target
Replace...	Initiates replacement of text in document

5.4 Format menu

The Format menu accesses typical text formatting functions, similar to those of any text editor.

Format menu options are:

Word Wrap	Enables or disables wrapping of text in entire document
Font...	Sets font of selected text
Colour...	Sets colour of selected text
Bold	Sets selected text to bold or non-bold
Italic	Sets selected text to italic or non-italic
Underline	Sets selected text to underline or non-underline
Paragraph	For paragraph at cursor: places/removes bullets, justifies left, centre or right

5.5 DSA-1 menu

The DSA-1 menu accesses all DSA-1 specific functions of the DSA-1 Manager.

These functions are described in the [Using the DSA-1 Manager](#) section; links to the appropriate sections are included in the menu list below.

Upload Results Log	Uploads the DSA-1 Results Log to the text window
Launch Remote Control	Launches the Remote Control window
Test Sequence	Submenu for compilation and downloading of Test Sequences
Download firmware upgrade	Updates the DSA-1's firmware
Select COM port	Allows selection of COM port for DSA-1 connection

5.6 Help menu

The Help menu contains two options:

Contents	Opens HTML Help file
About...	Displays DSA-1 Manager version

6 Test Sequence authoring guide

The following sections contain a description of the various [elements of a Test Sequence](#) and also a detailed [language reference](#).

6.1 Elements of a Test Sequence

This section gives a brief overview of the structure of a DSA-1 Test Sequence. It is recommended that the reader refer to the listings of the built-in sequences (shipped with this software) which provide useful examples.

The idea of a Test Sequence is that an operator can select and run a particular set of tests on an input carrier, and be informed that these have all been accomplished successfully. This gives a high degree of confidence in a very short time. Any failure is accompanied by an informative message, after which the whole Sequence can be restarted, or the offending part can be repeated, or that part can be skipped and the remainder of the Sequence can be run.

Thus Test Sequences are built up from one or more 'Segments'. Each Segment may run successfully or may fail. The name and number of each Segment is displayed on the DSA-1's display while it is running, and accompanies any failure message sent from that Segment. The Segment boundaries are also the only point at which the Sequence can be restarted if partial execution is desired.

The body of each Segment is made up of a number of 'Instructions', 'Labels' and 'Comments'. Each Segment has a Start Instruction (which includes the name of the Segment), and one or more End Instructions. A PASS/FAIL flag must be appropriately set before executing the Segment End instruction, in order to govern whether the Sequence will stop and display a message (FAIL) or carry on to the next Segment (PASS).

The following example shows a very simple Segment called 'Carrier lock' which FAILS if the selected DI is unlocked, displaying the message 'No carrier lock'; otherwise the Segment PASSES. It would be unusual to write a Segment as simple as this, since normally a Segment contains a number of related tests rather than just one. The operation of the example Segment should be clear to anyone who has written a computer program in almost any language:

```
/* Segment 1: tests that carrier is locked */
SEGMENT( 1, 'Carrier lock');
SET_FAIL;
TEST_UNLOCK_BIT; JUMP_IF_ZERO(@lock_ok);
MESSAGE( 'No carrier lock '); SEGMENT_END;
@lock_ok:
SET_PASS;
SEGMENT_END;
/*****/
```

Instructions may appear on lines on their own, or with several on one line separated by semicolons (;) as in the example above. Instructions may be 'simple', with no parameters, or they may be 'complex' with following parameters enclosed in brackets:

SET_PASS is an example of a simple Instruction

MEAS_FS_JITTER(6) is a complex Instruction

Complex Instructions are followed by one or more parameters in brackets, separated by commas. Parameters may be:

- Numeric (binary, base 10 or hexadecimal);
- Text (in single quotes);
- A Label (without the final colon);

Labels are typically targets for branching ('jump') Instructions. A Label is distinguished from an Instruction by starting with the '@' character and ending with a colon (':'), for example:

```
@MYLABEL:
```

Labels may be on a line on their own, or may precede one or more Instructions on the same line.

Comments may be added to the segment definitions in two ways; enclosed within '/' and '/' delimiters or with the '//' form which defines a Comment that lasts to the end of a line:

```
/* This is a comment */      JUMP(@start)

// So is this, anything on this line is ignored from here
```

Comment text is ignored by the compiler and serves only to make a Test Sequence source file easier to read.

6.2 Language reference

This section details the use of all Test Sequence keywords.

Sequence Start and End

A HEADER Instruction MUST be the first Instruction in the source file. It defines the start of the Test Sequence, and includes a 16 character text message that appears on the DSA-1 display when the Sequence is selected or run, for example:

```
HEADER('Special Test      ')
```

Similarly, the final Instruction of the Sequence should be:

```
END
```

Segment Start and End

These Instructions define the beginning and end of a Segment (the concept of a Test Sequence Segment is described above). Here is an example of a Segment start Instruction; the first parameter defines the running-order position of the Segment, the second is a message to be displayed when the segment runs or fails:

```
SEGMENT( 3, 'fs Tests      ')
```

The Segment end instruction has no parameters and causes the DSA-1 to skip to the beginning of the next segment, or to end the sequence if there are no more Segments (or if the Segment has failed):

```
SEGMENT_END
```

Set switches

These Instructions have no parameters and are used to set the DSA-1 switched operating parameters:

SELECT_COAX	Digital Input (DI) selection
SELECT_XLR	
SELECT_OPT	
SELECT_CHANA	Sub-frame (channel) selection
SELECT_CHANB	
SELECT_JITTERCF_HI	Jitter PLL corner-frequency selection
SELECT_JITTERCF_LO	
SELECT_EYE_AT_ZEROX	Threshold voltage for eye-narrowing measurement
SELECT_EYE_AT_200MV	
SELECT_LOZ	Select DI termination state
SELECT_HIZ	
CLEAR_ERROR_COUNT	Clear the biphas/parity error counter
CLEAR_LOG	Clear the Results Log
INSERT_LOG_BLOCK	Insert a Block Marker into the Results Log
CLEAR_LOG_LAST_BLOCK	Clear the Results Log back to last Block Marker

Test binary results

These Instructions cause a snapshot of a particular DSA-1 operating parameter to be loaded into the 16-bit Test Register. For most of these Instructions, the value is only a single bit, which is loaded into the least-significant bit of the Test Register with the upper 15 bits zeroed. Where indicated, a longer value is loaded at the least-significant end of the Test Register with the remaining upper bits zeroed.

TEST_UNLOCK_BIT	CARRIER panel 'FAIL' LED; 1 if lit
TEST_NFAIL_BIT	CARRIER panel 'N.FAIL' LED; 1 if lit
TEST_BLOCKERR_BIT	CARRIER panel 'BLOCK' LED; 1 if lit
TEST ALOG_BIT	CARRIER panel 'ALOG' LED; 1 if lit
TEST_AUX_BITS	DATA panel 'AUX' LED; 1 if lit
TEST_AUDL_BITS	DATA panel 'AUDIO' (low-bits) LED; 1 if lit
TEST_AUDMAIN_BITS	DATA panel 'AUDIO' (main bits) LED; 1 if lit
TEST_V_BIT	DATA panel 'V' LED; 1 if lit
TEST_U_BIT	DATA panel 'U' LED; 1 if lit
TEST_ANEB_BIT	DATA panel 'A<>B' LED; 1 if lit
TEST_CRCERR_BIT	DATA panel 'CRC ERROR' LED; 1 if lit
TEST_COAX	1 if [DI] is set to 'COAX'
TEST_XLR	1 if [DI] is set to 'XLR'
TEST_OPT	1 if [DI] is set to 'OPT'
TEST_LOZ	1 if [TERM] is set to 'LO-Z'
TEST_HIZ	1 if [TERM] is set to 'HI-Z'
TEST_CHANA	1 if [CHAN] is set to 'A'
TEST_CHANB	1 if [CHAN] is set to 'B'
TEST_JITTERCF_HI	1 if jitter PLL corner-frequency is low
TEST_JITTERCF_LO	1 if jitter PLL corner frequency is high
TEST_EYE_AT_ZEROX	1 if threshold for eye-narrowing is at 0-xing
TEST_EYE_AT_200MV	1 if threshold for eye-narrowing is at 200mV
TEST_LOG_FULL	1 if Results Log is full
TEST_REF_STATUS	(8-bit) loads Ref_Status register: Bit1, 1 if Ref AES11 Rx is unlocked Bit3, 1 if Ref Coax input is active Bit4, 1 if Ref XLR input is active Remaining bits undefined
TEST_CSBYTE (n)	(8-bit, n=0..23) loads DI Chan Status byte n

Measure numeric results

These Instructions cause a test to be performed using the specified DSA-1 function, after which the numeric result is loaded into the Test Register in the units indicated. Some of the Instructions require that a *'time'* parameter is specified which determines how long the measurement is averaged before

loading the result.

MEAS_ERROR_COUNT	Biphase/parity error count
MEAS_FS_JITTER(<i>time</i>)	fs jitter (ns)
MEAS_DATA_JITTER(<i>time</i>)	Data jitter (ns)
MEAS_EYE_NARROW(<i>time</i>)	Eye-narrowing (ns)
MEAS_DIF_AMPL	Differential input amplitude (V)
MEAS_CM_AMPL	Common-mode input amplitude (V)
MEAS_LOBAND_AMPL	Audio band input level (V)
MEAS_FS_BASE	Base fs of DI input returns 0(32k), 1(44k056), 2(44k1), or 3(48k)
MEAS_FS_ERROR	fs error from the standard rate (ppm)
MEAS_PHASE	Carrier phase versus Ref Sync (degrees)

Those Instructions which take *time* (i.e. measurement duration) as a parameter use units of seconds if the 's' suffix is specified, or tenths of a second if not, e.g.:

```
MEAS_DATA_JITTER(4.5s)
or
MEAS_DATA_JITTER(45)
```

would both measure Data Jitter over a period of 4.5 seconds.

Boolean operators

These Instructions cause a boolean operation to be performed on the Test Register, and are used to operate on the result of a previous TEST_.. Instruction (normally TEST_REF_STATUS or TEST_CSBYTE(n), see above). Conditional branch Instructions may then be used to vary action according to the results of the boolean operation.

AND(<i>value</i>)	Bitwise AND operation: new result = old result AND value
OR(<i>value</i>)	Bitwise OR operation: new result = old result OR value
XOR(<i>value</i>)	Bitwise XOR operation: new result = old result XOR value

'*value*' is a 16-bit word value expressed either as hexadecimal with a following 'h', binary with a following 'b' or decimal without either. '*value*' is enclosed in brackets.

Sequence flow

These Instructions cause the DSA-1 to branch or 'jump' to another part of the Sequence. Care should normally be taken never to branch outside the current Segment; although this is not specifically prevented, it is only occasionally useful and, if used unwisely, can cause unpredictable results.

The conditional branch Instructions enable different responses to occur depending on the results of previous TEST_.. or MEAS_.. operations. All JUMP_.. Instructions have a label description (starting with a '@' character) as their last parameter. Some also have a hexadecimal, decimal or binary value as the first parameter. Note that all the JUMP_.. Instructions have a 'short form' as shown in the list below.

Conditional branch Instructions act upon the current contents of the Test Register but do not change it, so that multiple JUMP_.. instructions may be used to test the same result several times.

JUMP(@label) or JMP(@label)	Unconditional
JUMP_IF_EQUAL(value, @label) or JE(..)	if result = value
JUMP_IF_NOT_EQUAL(value, @label) or JNE(..)	if result <> value
JUMP_IF_GREATER_THAN(value, @label) or JG(..)	if result > value
JUMP_IF_LESS_THAN(value, @label) or JL(..)	if result < value
JUMP_IF_GREATER_OR_EQUAL(value, @label) or JGE(..)	if result >= value
JUMP_IF_LESS_OR_EQUAL(value, @label) or JLE(..)	if result <= value
JUMP_IF_ZERO(@label) or JZ(..)	if result = 0
JUMP_IF_NOT_ZERO(@label) or JNZ(..)	if result <> 0
JUMP_IF_MASKED(value, @label) or JMASKZ(..)	if (result AND value) = 0
JUMP_IF_NOT_MASKED(value, @label) or JMASKNZ(..)	if (result AND value) <> 0

The @label parameter must begin with a '@' character. Note that labels when referred to in a JUMP.. instruction do not have a following colon (':') character. Jumps may be made backwards or forwards.

The JMASKZ and JMASKNZ instructions are most useful for testing Channel Status fields.

Notes on the 'value' parameter:

The value parameter can be expressed in a variety of units depending on what type of result is being tested. Usually there is a 'user-friendly' unit which requires the use of a suffix. Omitting the suffix causes the DSA-1's internal 'raw' units to be used:

Time (MEAS_FS_JITTER, MEAS_DATA_JITTER, MEAS_EYE_NARROW)

Use units of nanoseconds, with the suffix 'ns';
Raw DSA-1 units are multiples of 1/64th of a nanosecond;

```
JUMP_IF_GREATER( 6.5ns, @bad_jitter )
```

is equivalent to

```
JUMP_IF_GREATER( 4160, @bad_jitter )
```

Amplitude (MEAS_DIF_AMPL, MEAS_CM_AMPL, MEAS_LOBAND_AMPL)

Use units of Volts or millivolts, with suffixes of 'V' or 'mV';
Raw DSA-1 units are multiples of 10 mV;

```
JUMP_IF_LESS_THAN( 240mV, @no_level)
```

is equivalent to

```
JUMP_IF_LESS_THAN( 24, @no_level)
```

Frequency (MEAS_FS_ERROR)

Use units of parts per million depending on the sampling frequency in use, with suffixes:

'PPM_480' if fs=48.0kHz
 'PPM_441' if fs=44.1kHz
 'PPM_440' if fs=44.056kHz
 'PPM_320' if fs=32.0kHz

Raw DSA-1 units are multiples of 1/64 Hz;

Phase (MEAS PHASE)

Use units of degrees with a suffix of 'DEG';
 Raw DSA-1 units are multiples of 360/512 degrees (about 0.703 degrees);

```
JUMP_IF_GREATER_THAN( 45deg, @notinphase)
```

is equivalent to

```
JUMP_IF_GREATER_THAN( 64, @notinphase)
```

Segment pass/fail operators

These Instructions set and act upon the PASS/FAIL flag. If set to FAIL before a Segment end, this flag causes the Sequence to abort. If set to PASS before a Segment end, the flag allows the sequence to continue.

SET_PASS	Set flag to 'PASS'
SET_FAIL	Set flag to 'FAIL'
JUMP_IF_PASS(@label) or JPASS(..	Jump if flag is set to 'PASS'
JUMP_IF_FAIL(@label) or JFAIL(..	Jump if flag is set to 'FAIL'

Miscellaneous

This Instruction displays a message on the bottom line of the DSA-1's display. The text parameter must be enclosed in single quotes:

```
MESSAGE(text)
```

The no-operation Instruction is:

```
NOP
```

This causes the DSA-1 to take no action and pass on to the next Instruction.

Long delays are accomplished with:

```
WAIT(delay)
```

The delay parameter can be expressed in seconds by using an 's' suffix, otherwise is assumed to be expressed in tenths of a second. There are a number of circumstances where delays need to be inserted, for example waiting for lock to be acquired after changing the [DI] selection.

7 Icons and Hotkeys reference

The following reference tables of icons and Hotkeys are available:

[Toolbar icons](#)

[Hotkeys \(short-cut keys\)](#)

7.1 Toolbar icons

The following toolbar icons operate in the DSA-1 Manager:

-  Open a new text document
-  Open an existing text document
-  Save a text document at the current location
-  Print the current document
-  Undo the last edit operation
-  Cut the selected text to the clipboard
-  Copy the selected text to the clipboard
-  Paste the contents of the clipboard at the cursor
-  Find specified text
-  Change the font of the selected text
-  Change the colour of the selected text
-  Bold/un-bold the selected text
-  Italic/un-italic the selected text
-  Underline/de-underline the selected text
-  Bullet/un-bullet the paragraph at the cursor
-  Left-justify the paragraph at the cursor
-  Centre-justify the paragraph at the cursor
-  Right-justify the paragraph at the cursor
-  Select the COM port for DSA-1 connection
-  Upload the Result Log from the DSA-1
-  Launch the DSA-1 Remote Control window
-  Compile a Test Sequence
-  Download a Test Sequence to the DSA-1
-  Update the DSA-1's firmware

7.2 Hotkeys (short-cut keys)

In addition to the usual Windows hotkeys, the following application-specific hotkeys operate in DSA-1 Manager:

F1	Launch on-line help
Ctrl + N	Open a new text document
Ctrl + O	Open an existing text document
Ctrl + S	Save a text document at the current location
Ctrl + P	Print the current document
Ctrl + Z	Undo the last edit operation
Ctrl + X	Cut the selected text to the clipboard
Ctrl + C	Copy the selected text to the clipboard
Ctrl + V	Paste the contents of the clipboard at the cursor
Ctrl + A	Selects all text in the text window
Ctrl + F	Find specified text
Ctrl + H	Replace specified text
Ctrl + B	Bold/un-bold the selected text
Ctrl + I	Italic/un-italic the selected text
Ctrl + U	Underline/de-underline the selected text
F3	Find the next occurrence of previous find text
F5	Refresh Test Sequence syntax colouring
F6	Compile a Test Sequence
F7	Download a Test Sequence to the DSA-1
F8	Launch the DSA-1 Remote Control window
F9	Select the COM port for DSA-1 connection
F10	Upload the Result Log from the DSA-1
F11	Update the DSA-1's firmware

Index

- A -

About DSA-1 Manager 11

- B -

Bullets 10

- C -

Cable 3
Colour 10
COM port 2, 3
Connection 3
Cut copy and paste 9

- D -

DSA-1 menu 10

- E -

Edit functions 9
Edit menu 9

- F -

File menu 9
Finding text 10
Firmware 7
Font 10
Format menu 10

- H -

Help menu 11
Hotkeys (short-cut keys) 19

- I -

Icons 18
Installation 3

- J -

Justification 10

- K -

Keyboard short-cuts 19

- L -

Loading documents 9

- M -

Manual 2
Menu reference 9

- N -

Null-modem cable 3

- O -

Operating system 2, 3

- P -

Printing documents 9

- R -

Remote Control 4
Replacing text 10
Results Log 4
RS232C 3

- S -

Saving documents 9
Search menu 10
Select All 9
Serial port 2
Short-cut keys 19
Software installation 3

- T -

Test Sequences 5, 12

Test Sequences 5, 12
 authoring 12
 compiling 5
 downloading 5
 elements 12
 language reference 13

Text format 10

Toolbar icons 18

- U -

Uploading the Results Log 4

USB adapter 2

User interface 4

User Test Sequences 5

- V -

Version information 11

- W -

Windows 2

Word Wrap 10